Battery Strap 16x250

Silicone battery strap
User Manual



Read this manual before use and keep it for future reference.

www.rotorama.com

Contents

1. Product Description

1.1 Intended use

1.2 Technical data and package contents

2. Use

2.1 Securing the battery

2.2 Safety and maintenance

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and Rights Arising from Defective Performance

1. Product Description

1.1 Intended use

Rotorama Battery Strap – Silicone 16x250 is a strap for securing the flight battery to a multicopter (FPV drone). It is threaded through the frame or the mounts under the battery, tightened around the battery through the metal buckle and secured with the hook-and-loop fastener.

One side of the strap is coated with an anti-slip silicone layer that helps hold the battery firmly in place. The metal buckle increases the durability of the strap when it is tightened repeatedly.



① metal buckle · ② hook-and-loop fastener · ③ anti-slip silicone layer

1.2 Technical data and package contents

Product designation	Rotorama Battery Strap – Silicone 16x250
Width	16 mm
Length	250 mm (according to the designation 16x250)
Weight	4.2 g
Fastening	metal buckle and hook-and-loop fastener
Surface	anti-slip silicone layer on one side
Package contents	1× battery strap

Not included: battery, drone or frame. The length and width are given so that you can check whether the strap will go around your battery together with the frame.

2. Use

2.1 Securing the battery

① Thread the free end of the strap through the strap slots in the frame (or run it underneath the frame) so that the metal buckle ends up on top, next to the battery.

② Place the battery on the frame. The anti-slip silicone layer must face **towards the battery**.

③ Wrap the strap around the battery and pass the free end through the metal buckle.

④ Pull the strap tight, fold it back and press the hook-and-loop fastener firmly along the whole overlap.

⑤ Check that the battery cannot shift in any direction and that neither the free end of the strap nor the power lead can reach the propellers.

To remove the battery, peel the hook-and-loop fastener apart and loosen the strap in the buckle. For heavier batteries or aggressive flying you can use two straps side by side.

2.2 Safety and maintenance

- Before every flight, check that the strap is tight, the hook-and-loop fastener holds firmly and the strap is not torn or worn through. A loose battery can fall out in flight or get into the propellers.
- Sharp edges of a carbon frame can wear through the strap. Route the strap so that it does not rub against an edge, and sand the edges down if necessary.
- Keep the hook-and-loop fastener clean — grass, sand and dust reduce its grip. Replace a worn or damaged strap.
- Do not tighten the strap so hard that it deforms or dents the Li-Po battery. Do not use a damaged battery.
- The strap is not a toy. Keep it out of the reach of small children.
- When operating a drone, follow the regulations of the country in which you fly — the law of the country in which the product is operated always prevails.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product is not electrical equipment and does not contain a battery.
- At the end of its service life, dispose of it with mixed municipal waste or according to the waste-sorting rules in your municipality. The metal buckle can be taken to metal collection.
- Sort the packaging by material into the appropriate recycling container.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.