TX16S Protector

Gimbal and switch protector for RadioMaster TX16S and TX16S MKII

User manual



Always remove the protector before switching the radio on.

www.rotorama.com

Contents

1. Product description

1.1 What it is for

1.2 Specifications and package contents

2. Use

2.1 Fitting the protector

2.2 Removing the protector

2.3 Care and storage

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 What it is for

The RadioMaster gimbal and switch protector is an injection-moulded TPU cover that fits over the front of a RadioMaster TX16S or TX16S MKII radio. It covers the most vulnerable parts of the radio – both gimbals with their sticks and the top row of switches – and protects them from being bent, broken off or otherwise damaged while the radio is carried in a backpack or bag, or kept in storage.

The protector is held on the radio by elastic straps that run around the body of the radio. Fitting and removing it is quick and needs no tools. The protector is intended **for transport and storage only** – it must be removed when flying.



Protector fitted on a TX16S radio

1.2 Specifications and package contents

Manufacturer	RadioMaster
Product designation	TX16S & TX16S MKII Gimbal and Switch Protector (code HP0157.TX16S-PROTEC)
Intended for	RadioMaster TX16S and TX16S MKII; the manufacturer specifically lists: TX16S Mark II, TX16S Mark II Max, TX16S Mark II Max Joshua Bardwell Edition, TX16S MKII Transparent Version, TX16S Mark II MAX Customized Version
Material	injection-moulded TPU
Mounting	elastic straps
Package contents	1× gimbal and switch protector
Not included	radio, carrying bag or case

2. Use

2.1 Fitting the protector

① Switch the radio off. Leave the gimbal sticks centred and the switches in their rest position.

② Place the protector on the front of the radio so that the round sections cover both gimbals and the raised top parts cover the switches along the top edge.

③ Run the elastic straps down the sides of the radio and around its bottom edge so that the protector sits firmly on the radio.

④ Check that the protector sits evenly, does not press on the sticks or switches anywhere, and that the straps do not cover any connectors or controls you want to keep free.



Protector with elastic mounting straps

2.2 Removing the protector

Loosen the straps, slide them off the bottom edge of the radio and carefully lift the protector off towards the front so that it does not catch on the gimbal sticks or the switches.

※ Always remove the protector before switching the radio on. When fitted, the cover can push the sticks or switches out of their rest position and restricts their operation.

2.3 Care and storage

- Clean the protector with a damp cloth, with a little mild detergent if needed, and let it dry. Do not use solvents or aggressive cleaning agents.
- Do not store it in direct sunlight or near heat sources (e.g. in a hot car) – the plastic could deform.
- Do not stretch the straps more than needed for mounting. If the straps or the protector are damaged or worn loose, stop using the protector – it may no longer protect the radio reliably.
- The protector does not protect the whole radio against drops or impacts; we recommend also using a suitable bag or case for transport.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product is not electrical equipment and contains no batteries. At the end of its life, dispose of it with sorted waste in accordance with local waste rules (plastics) or take it to a municipal collection point.
- Sort the packaging according to its material.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.