Cineon C35 Guard

Replacement propeller guards (ducts) for the Axisflying Cineon C35 frame
User manual



Always disconnect the drone's battery before replacing the guards.

www.rotorama.com

Contents

1. Product description

1.1 Purpose

1.2 Specifications and package contents

2. Use

2.1 Before you start

2.2 Replacing a guard

2.3 Check after installation

2.4 Care and condition check

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Purpose

This product is a set of replacement plastic propeller guards – ducts – for the **Axisflying Cineon C35** frame. The set contains two parts. Each part consists of a pair of circular ducts joined by a central strut and protects the two propellers on one side of the drone.

The guards are used to replace original ducts that have been damaged – for example cracked after an impact or crash. The duct surrounds the propeller, reduces the risk of the propeller hitting an obstacle and protects both the surroundings and the propellers themselves on contact with objects.



The set contains two parts – the left and the right pair of ducts.

1.2 Specifications and package contents

Product designation	Axisflying Cineon C35 Guard (2pcs/bag)
Manufacturer	Axisflying
Compatibility	Axisflying Cineon C35 frame
Propeller size	max. 3.5" (according to the manufacturer's data for the Cineon C35 frame)
Type	plastic spare part, no electronics
Package contents	2 pcs guards (left and right pair of ducts)
Not included	frame, propellers, screws and other fasteners, tools

2. Use

2.1 Before you start

- Always carry out the replacement with the **battery disconnected**. Accidental start of the motors (Arm) while working on the drone can cause serious injury.
- Remove the propellers for easier access to the mounting points.
- Prepare a suitable screwdriver or wrench for the frame's original screws. Fasteners are not included – use the original screws from the frame; replace damaged or stripped screws with identical ones.
- Work on a clean surface so that small parts do not get lost.

2.2 Replacing a guard

① Loosen and remove the screws that hold the damaged guard to the frame. Keep the screws.

② Remove the damaged guard from the frame. Remember or take a photo of its position and orientation.

③ Fit the new guard on the same side of the frame in the same orientation as the original part. The mounting holes of the guard must line up with the holes in the frame.

④ Insert the screws and tighten them gently. Do not overtighten the plastic part – excessive force can crack it.

⑤ Refit the propellers according to the instructions for your drone and check their direction of rotation.

2.3 Check after installation

- With the battery disconnected, turn each propeller by hand. The propeller must not touch the duct at any point.
- Check that the guard is held firmly and does not wobble when pressed lightly.
- Only then connect the battery and carry out the usual pre-flight check.
- The operation of the drone is governed by the laws of the country in which you operate it.

2.4 Care and condition check

- Inspect the guards after every impact or crash. Replace a cracked, deformed or loose guard – it may come into contact with the propeller.
- Check that the screws are tight; vibration can loosen them over time.
- Remove dirt with a soft cloth, or a damp cloth with a little detergent. Do not use solvents, which may damage the plastic.
- Do not store the guards in direct sunlight or near heat sources.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product is a plastic part and **contains no electronics or batteries**. It is not electrical equipment.
- Dispose of an unusable guard in sorted waste according to the rules of your municipality. Do not discard it in nature.
- Sort the packaging according to the type of material.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.