Battery Strap 20x350

Rubberized Kevlar – strap for securing the battery
User manual



Read this manual before first use and keep it for future reference.

Rotorama, s.r.o. · www.rotorama.com · info@rotorama.cz

Contents

1. Product description

1.1 Purpose

1.2 Technical data and package contents

2. Use

2.1 Securing the battery

2.2 Inspection, care and safety

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Purpose

Rotorama Battery Strap – Rubberized Kevlar 20x350 is a Kevlar strap for securing the battery to the frame of a model. Thanks to the material used and the metal buckle, the strap is very durable. The metal buckle is made in one piece, without a weld.

The strap is stitched with rubber, so it does not slip on the battery and holds it firmly. The logo on the strap is coloured and embroidered. The 350 mm length is suitable especially for long-range quadcopters and cinelifters with larger batteries.



Strap fastened into a loop

1.2 Technical data and package contents

Product designation	Rotorama Battery Strap – Rubberized Kevlar 20x350
Material	Kevlar with rubber
Buckle	metal, one piece without a weld
Dimensions	20 × 350 mm (width × length)
Package contents	1× strap
Not included	battery, frame, anti-slip battery pad

2. Use

2.1 Securing the battery

The strap is threaded through the strap slots in the frame, wraps around the battery and is fastened through the metal buckle.

① Thread the free end of the strap through the strap slots in the frame so that the metal buckle stays on one side of the battery.

② Place the battery in its intended position on the frame – on the anti-slip pad, if the frame has one.

③ Lead the free end of the strap over the battery, pass it through the metal buckle and fold it back.

④ Pull the strap tight and press the end firmly against the strap along its whole surface so that it fastens.

⑤ Check that the battery cannot be moved or rotated by hand, that the strap does not pinch the cables or the connector, and that no part of the strap reaches into the path of the propellers.

※ The excess end of the strap must not flap freely. A loose end could be struck by a propeller.

2.2 Inspection, care and safety

- **Before every flight**, check that the strap is not torn, frayed or cut and that it holds reliably when fastened.
- Sharp edges of a carbon frame can gradually cut through the strap. Check the edges of the strap slots regularly.
- Replace a damaged strap, or a strap that does not hold when fastened, immediately. A loose battery may fall out in flight or shift the model's centre of gravity.
- Do not overtighten the strap with a force that would deform the battery. A damaged Li-Po battery is dangerous.
- Keep the fastening surfaces clean. Sand, grass and dirt reduce their grip.
- The strap is intended only for securing the battery to the model. Do not use it for lifting or suspending loads.
- Store it out of the reach of children.

3. Information for the EU and Czech Market

The information in Chapters 3 and 4 is based on the legislation of the European Union and the Czech Republic. If you use the product in another country, the law of the country in which you use it is decisive.

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The strap **is not electrical or electronic equipment** and is not subject to the take-back of electrical equipment.
- Dispose of a worn or damaged strap with mixed municipal waste unless the waste sorting rules of your municipality specify otherwise. The metal buckle can be separated and taken to metal waste or a collection yard.
- Sort the packaging material by type into the appropriate recycling containers.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.