Small Foam Pads

Self-adhesive foam pads, pack of 8
User manual



Read this manual before use and keep it for future reference.

www.rotorama.com

Contents

1. Product description

1.1 Purpose

1.2 Specifications and package contents

2. Use

2.1 Placement on the frame

2.2 Attaching the pads

2.3 Inspection, replacement and warnings

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Purpose

These small self-adhesive foam pads serve as **landing pads** for FPV frames with the battery mounted on the top plate. They are stuck to the underside of the bottom plate, so that on landing the drone touches down on soft foam rather than directly on the frame and the components on its underside.

Thanks to their dimensions of 10 × 25 × 8 mm, the pads are suitable for smaller 3" and 4" frames. The pack contains 8 pads – enough for one frame with spares for later replacement, or for several frames.



Foam pads (illustrative photo, 4 pcs shown)

1.2 Specifications and package contents

Product designation	Small foam pads 8 pcs
Product type	foam pads with adhesive (self-adhesive)
Dimensions of one pad	10 × 25 × 8 mm
Intended use	landing pads for smaller 3" and 4" frames
Package contents	foam pads, 8 pcs
Not included	frame, battery, cleaning agents or any other mounting accessories

2. Use

2.1 Placement on the frame

The pads are stuck to the underside of the frame so that the drone stands stably after landing and nothing else touches the ground.

- Place the pads **symmetrically** – typically one or two under each arm or in the corners of the bottom plate – so that the drone stands level and does not tip over.
- The pads must not cover screw holes, connectors, buttons, LEDs, the camera or antennas, and must not obstruct access to the flight controller (FC).
- Make sure that neither the pads nor their edges reach into the path of the propellers.
- Try out the placement before sticking, while the adhesive backing film is still in place.

2.2 Attaching the pads

① Disconnect the battery and remove the propellers.

② Clean and degrease the bonding area (e.g. with isopropyl alcohol) and let it dry completely. The adhesive will not hold on dust, oil or a damp surface.

③ Peel the backing film off the pad without touching the adhesive surface with your fingers.

④ Place the pad in the chosen position and press it firmly over its entire surface.

⑤ Repeat for the remaining pads. After attaching, give the adhesive some time to set before the first flight.

2.3 Inspection, replacement and warnings

- After a crash or a hard landing, check that the pads are still firmly attached and not torn. A loose pad may detach in flight.
- Remove a worn or detached pad, clean the adhesive residue off the frame and attach a new pad as described in Chapter 2.2.
- Store unused pads in a dry place away from direct sunlight so that the adhesive does not lose its tack.
- Small parts – keep out of the reach of small children; risk of inhalation or swallowing.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product **is not electrical equipment** and contains no batteries or accumulators.
- Dispose of worn pads in accordance with the waste sorting rules of your municipality. Hand the packaging over for separate collection according to its material.
- The waste management rules of the country in which you use the product shall prevail.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.