ROTORAMA

Axisflying C25

Replacement propeller guards
User manual



Read this manual before installation and keep it for future reference.

www.rotorama.com

Contents

1. Product description

1.1 Purpose

1.2 Specifications and package contents

2. Use

2.1 Safety instructions

2.2 Replacing the guards

2.3 Inspection and maintenance

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Purpose

Replacement plastic propeller guards are designed for the **Axisflying Cineon C25** frame – a small cinewhoop with 2.5" propellers. The guards surround the propellers and protect them, as well as the drone's surroundings, on contact with an obstacle. They replace cracked, deformed or otherwise damaged original guards.

The set consists of two parts. Each part is made up of two connected rings, and together they surround all four propellers. The parts are attached to the frame with screws through mounting lugs with holes.



Axisflying C25 replacement guards (set of two parts)

1.2 Specifications and package contents

Product designation	Axisflying C25 – replacement guards
Manufacturer	Axisflying
Compatibility	Axisflying Cineon C25 frame
Material	plastic
Package contents	1× set of guards (2 parts)
Not included	screws, propellers, frame or other drone parts

※ The manufacturer does not publish the weight, dimensions or exact type of plastic.

2. Use

2.1 Safety instructions

- Always replace the guards with the **battery disconnected**. Unintended motor start-up can cause injury.
- The guards reduce the risk of damage on contact with an obstacle, but they **do not guarantee** the safety of people or animals. Keep a safe distance and follow the drone regulations of the country where you fly.
- Do not fly with a cracked, deformed or loose guard – the propeller could strike it, or the part could come loose in flight.
- Keep small parts and screws out of the reach of children.

2.2 Replacing the guards

① Disconnect the battery and remove the propellers.

② Loosen and remove the screws that hold the damaged guard to the frame. Keep the screws – they are not included in the package.

③ Remove the damaged part and fit the new one so that the mounting lugs line up with the holes in the frame.

④ Insert the screws and tighten them with moderate force. Overtightening cracks the plastic lugs.

⑤ Refit the propellers and turn them by hand. The blades must not touch the guard in any position.

⑥ Before the first flight, check in a safe area that the propellers spin freely and nothing rubs.

2.3 Inspection and maintenance

- After every impact, check that the guard is not cracked and that the screws are tight.
- Replace a bent or cracked guard – gluing or straightening will not restore its original strength.
- Clean the guards with a dry or slightly damp cloth, without solvents.
- Do not store them in direct sunlight or near heat sources; the plastic could deform.

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

3.2 Disposal

- The product contains no electronics or batteries. At the end of its service life, dispose of it as sorted waste according to local rules – in a plastics container or at a collection yard.
- Sort the packaging according to the type of material.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.